

Using the Tecco color profiles in Adobe Photoshop CS and CS2

For some papers are two kinds of profiles available. Profiles ending with P are especially generated for portrait photography; profiles ending with T are suitable for any other subjects. To achieve optimal printing results with Tecco color profiles the following settings in Adobe Photoshop and in the printer driver should be used.

Information for the settings in the printer driver you find on page 3 of this manual.

1 Activating the .icc profile

Before you can use the profile, it must be made available in the operating system. To activate the profile, hold down the right mouse button and choose **Install Profile (Profil installieren)** from the context menu.


2.1 Printer pre settings

Go to **File\Print preview...**
Click **Page Setup...** to select the desired paper size.


2.2 Printer pre settings in Adobe Photoshop CS

Configure all settings according to the illustration on the right: Activate **Show More Options\Color Management**. Select the Tecco profile as the setting for **Print Space Profile** and the priority setting **Perceptual** and deactivate **Use Black Point Compensation**.

1 Activating the .icc profile



2.2 Printer pre settings in Adobe Photoshop CS



2.3 Printer pre settings in Adobe Photoshop CS 2

Configure all settings according to the illustration on the right: Activate **Show More Options\Color Management**. Select **Let Photoshop Determine Colors** as setting for **Color Handling** and choose the **Tecco color profile** as setting for **Printer Profile** and deactivate **Use Black Point Compensation**.

Advice to 2.2 and 2.3

If our profile does not appear in Adobe Photoshop please reboot Adobe Photoshop.

3 Settings in the printer driver


For the settings in the printer driver please refer to the table on page 3 of this manual.

3.1 Color Management settings in the printer driver

Deactivate the color management in the printer driver.

If you have made all settings as described in point 2 to 3 you can start printing by clicking **print**.

2.3 Printer pre settings in Adobe Photoshop CS2



Epson Stylus Pro 4800	Medium	Quality	High Speed	Paper Thickness	Color Density	Profile
mediaware Digital Photo PD170 DUO-Matt	Photo Glossy Paper	2880 dpi	on	2		TC_4800_PD170_2880_100705P.icc TC_4800_PD170_2880_100705T.icc
mediaware Digital Photo PM230 Matt	Photo Glossy Paper	2880 dpi	on	2		TC_4800_PM230_2880_100705P.icc TC_4800_PM230_2880_100705T.icc
mediaware Digital Photo PPM190 Pastell-Matt	Enhanced Matte Paper	2880 dpi	on	2		TC_4800_PPM190_2880_050106P.icc TC_4800_PPM190_2880_050106T.icc
mediaware Digital Photo FM160 Film Matt	Photo Glossy Paper	2880 dpi	on	2		TC_4800_FM160_2880_100705P.icc TC_4800_FM160_2880_100705T.icc
mediaware Digital Photo TB180 Textile Banner	Archival Matte Paper	2880 dpi	on	Standard	-20	TC_4800_TB180_2880_150607T_-20fabcp.icc
mediaware Digital Photo PPG250 Pearl-Gloss Super	Photo Glossy Paper	2880 dpi	on	2		TC_4800_PPG250_2880_090705P.icc TC_4800_PPG250_2880_090705T.icc
mediaware Digital Photo PHG260 High-Gloss	Photo Glossy Paper	2880 dpi	on	2		TC_4800_PHG260_2880_090705P.icc TC_4800_PHG260_2880_090705T.icc
mediaware Digital Photo PDG250 DUO-Gloss	not supported					
mediaware Digital Photo PUW285 Glossy Ultra White	Photo Glossy Paper	2880 dpi	on	2		TC_4800_PUW285_2880_090705P.icc TC_4800_PUW285_2880_090705T.icc
mediaware Digital Photo PL285 Luster	Premium Luster Photo Paper	2880 dpi	on	3		TC_4800_PL285_2800_200306P.icc TC_4800_PL285_2800_200306T.icc
mediaware Digital Photo PBW560 Posterboard Ultra White	Premium Semiglossy Photo Paper	2880 dpi	on	15		TC_SP4800_PBW560_1440_130607T.icc
mediaware Digital Photo GB330 Gallery Board	Photo Glossy Paper	2880 dpi	on	9		TC_4800_GB330_2880_100705P.icc TC_4800_GB330_2880_100705T.icc
mediaware Digital Photo BP210 Büttelpapier	Photo Glossy Paper	2880 dpi	on	2		TC_4800_BP210_2880_100705P.icc TC_4800_BP210_2880_100705T.icc
mediaware Digital Photo PFR290 FineArt Rag	Archival Matte Paper	1440 dpi	off	6		TC_4800_PFR290_1440_090707T.icc
mediaware Digital Photo CPP340 Canvas Pro Plus	Photo Glossy Paper	2880 dpi	on	9		TC_4800_CPP340_2880_020806P.icc TC_4800_CPP340_2880_020806T.icc
mediaware Digital Photo CS350 Canvas Satin	Premium Semigloss Photo Paper (250)	1440 dpi	off	9		TC_4800_CS350_1440_141106T.icc
mediaware Digital Photo BT270 Baryt	Premium Semimatt Photo Paper (250)	2880 dpi	on	6		TC_4800_BT270_2880_161106T.icc
mediaware Digital Photo BTI290 Baryt Paper Ivory	Premium Semimatt Photo Paper (250)	2880 dpi	on	6		TC_4800_BTI290_2880_251007T.icc
mediaware Digital Photo PWF130 White Film Ultra-Gloss	Premium Glossy Photo Paper (170)	2880 dpi	on	4		TC_SP4800_PWF130_2880_121207T.icc
mediaware Digital Photo PSR250 Portrait Silk Raster	Photo Semigloss Paper	2880 dpi	on	4		TC_4800_PSR250_2880_310108T.icc
mediaware Digital Photo SGD DUO Semigloss	Premium Semigloss Photo Paper	1440 dpi	on			TC_SP4800_SGD250_1440_010708.icc

Tecco color profiles for Epson Stylus Pro 4800